

PL
INSTRUKCJA MONTAŻU/OPIS

UWAGA!

Dla uzyskania maksymalnej mocy cieplnej grzejnika zaleca się zachowanie minimalnych odległości:

- 10 cm od parapetu
- 2,5 cm od ściany
- 10 cm od podłogi

1. Za pomocą poziomicy wyznacz linię montażową poziomą i pionową. Zaznacz punkty które pozwolą na dokładne zamontowanie wsporników pionowych.
2. Zmierz szerokość grzejnika i dopasuj punkty montażowe, tak aby ciężar grzejnika został równomiernie rozmieszczony.
3. Nawierć otwory pod kołki rozporowe i zamocuj wsporniki.
4. Po zamontowaniu wsporników sprawdź prawidłowość montażu za pomocą poziomicy.
5. Załóż grzejnik na zamontowane wsporniki i podłącz grzejnik do instalacji.

Zestaw zawiera:

- 2 uchwyty (wsporniki)
- 4 kołki rozporowe
- 4 śruby + zaślepki

EN
ASSEMBLY MANUAL/DESCRIPTION

NOTE!


To obtain the maximum heat output of the radiator, it is recommended to keep the minimum distances:

- 10 cm from the windowsill
- 2.5 cm from the wall
- 10 cm from the floor

1. Use the level to mark the horizontal and vertical lines. Mark the points that will allow you to accurately mount the vertical brackets.
2. Measure the radiator width and adjust the mounting points so that the weight of the radiator is evenly distributed.
3. Drill holes for wall plugs and attach the brackets.
4. After mounting the brackets, check if the mounting is correct using a level.
5. Put the radiator on the mounted brackets and connect it to the system.

The set contains:

- 2 handles (brackets)
- 4 wall plugs
- 4 screws + hole plugs



Data naprawy Date of repair	Pieczętka serwisu Stamp of service
.....	
.....	
.....	

Data naprawy Date of repair	Pieczętka serwisu Stamp of service
.....	
.....	
.....	

Index

Pieczętka punktu sprzedaży / Stamp of the seller
Data sprzedaży / Date of sales
Podpis / Signature